TD0503018S3

Digital Audio Player

SV-MP510VGK / SV-MP510VGH / SV-MP510VGC / SV-MP510VGD / SV-MP510VGN

Colour
(A).....Blue Type
(W).....White Type

Service Notice /
Please use this supplement manual together with the service manual for Model No. SV-MP510V(GK/GH/GC/GD/GN),Order No. TD0411062C3

PDF created with pdfFactory Pro trial version www.pdffactory.com

SPECIFICATIONS

Service Precautions

- Install and Copy the software (DFU,firmware,font table) After replacing the main PCB and DSP IC (main CPU),reinstall DFU and firmware,and copy font table again.
- Please contact to the service organization of the belonging for the acquisition of data and obtain the software.

© 2005 Matsushita Electric TAIWAN Industrial Co., Ltd. All rights reserved. Unauthorized copying and distribution is a violation of law.

Panasonic

1. Instructions for Repair Service

PDF created with pdfFactory Pro trial version www.pdffactory.com

How to Set the unit after Repair
Please adjust the unit settings with the following directions after the below part is replaced:

	Exchange Parts	Content
A	DSP IC	① Install the software by using DFU. ② Copy the Font table into the root directory.
B	Flush-ROM	Copy the Font table and software into the root directory.

Please follow below instruction when you need to replace PWB included DSP IC or Flush-ROM.

< Procedure >

1. Preparation

Download the necessary software (DFU, Firmware, Font table) from TSN-WEB
(Support Information From NWBG-PAVC).

(NOTE) If you may not be able to complete a downloading from the above TSN-WEB page,
Please obtain the data through your local Panasonic Service Organization.

A (DSP IC):

2. Enter the Service Mode (Refer to the Inspection Procedure of DSP-IC).
3. Install the Firmware Soft by using DFU.
4. Copy the Font Table (into the route directory in the unit).
5. Unplug the USB cable and Jumper pin after installing.
6. Follow the check procedure to confirm DSP-IC and Font Table is set.

B (Flash-ROM):

2. Copy the Firmware Soft and Font Table into the root directory in the unit.
3. Unplug the USB cable.
4. Follow the check procedure to confirm DSP-IC and Font Table is set.

Printed in Taiwan / T0503 TSAI

PDF created with pdfFactory Pro trial version www.pdffactory.com